

DE 4 port USB Hub




Warning: If devices are high drain such as tablets or 2 Amp devices, plug a micro charger into the micro port (3) to give it added power. Too much power being drained will cause device and possibly your personal computer to stall.



WWW.DIGITALENERGYWORLD.COM

4 PORT USB HUB USB TYPE C OR A to USB TYPE A



- 1 USB Type C Input
- 2 USB Type A Adapter
- 3 Micro Additional Power Port
- 4 USB Type A Input X4

Specifications:

Dimensions..... 2.75 x 1.6 x .45 in
Weight..... .5oz
Ports..... 4 USB 3.0 Type A Ports
Power Supply Via..... USB Type C or Type A Adapter

Includes:

4 Port USB Hub
USB Type A Adapter

Directions:

- 1) Plug the USB hub with its USB Type C tip or Type A adapter tip into your USB port.
- 2) Plug in your USB devices into the ports.
- 3) Charge and sync your devices.
- 4) If using multiple high powered devices, be sure to read the warning on the reverse side.

