

QUIK SHADE® Set-Up and Safety Instructions

Do not call store regarding set up issues, missing parts or any questions. Instead, please contact Bravo Sports directly at 800-248-5327

Before proceeding with the assembly of your QUIK SHADE® Instant Canopy, please make yourself familiar with its parts and how they make your QUIK SHADE® function.

Set Up

Step 1

Place your QUIK SHADE® in the center of the set-up area. With a partner on the opposite side of the frame, hold onto the two outer legs and lift slightly for clearance. Take a few steps backward until you have extended the frame a full arms length – approx. 4 feet (fig. A). To improve the opening and closing action of your QUIK SHADE®, you may spray some silicone lubricant on the outer legs.



Step 2

Place the canopy over the top of the frame (fig. B). Use the hook and loop straps to secure each corner of the cover to the frame under the plastic caps or steel bracket (fig. C).



Step 3

Grab the bottom of the middle frame section where it forms a "V" and has the words "OPEN" (fig. D). Lift slightly and slowly walk backward until the frame is fully extended (fig. E). Take care to avoid pinching your hands or fingers.



Step 4

At each corner, hold the leg of the frame with one hand and lift the slider. Push the locking button in while pulling the slider up until the button pops through (fig. F). You can also snap the slider in place by pulling it up until the button pops through. For the commercial series, sliders will lock in place as shown (fig. G).



Step 5

Secure remaining side hook and loop straps to the frame (fig. H). The adjustable legs offer multiple height levels. To adjust, lift the leg up and slowly pull out the inner leg until the button pops into place (fig. I). Repeat on the other legs. Use the stakes to secure frame to the ground in necessary.



Final



The following parts are inside your QUIK SHADE® box:

1 QUIK SHADE® Assembled Frame

1 Canopy Top

1 Wheeled Bag

4 Stakes

NOTE: Your canopy may or may not come with a wheeled bag. Please check box for list of contents.

Take Down

Note: The canopy may remain in place for easier subsequent set-up, however, to prolong the life of the canopy, we recommend that you remove it during take-down.

WARNING: Before storing your QUIK SHADE®, be sure the canopy is not wet or damp. Storing your QUIK SHADE® while it is even slightly damp may cause mildew. Allow your canopy to completely dry before taking it down. If you must take down your QUIK SHADE® while the canopy is damp, remove the canopy from the frame by unfastening the hook and loop straps. Fold up the frame and lay the canopy down, fully open, as soon as possible and allow it to completely dry.

Step 1

Remove stakes from ground. Reduce each leg to its shortest position (fig. I).



Step 2

At each corner, push in the locking button and pull the slider down slowly until the button pops out above the slider (fig. J). For commercial units, pull ring out and move sliders down (fig. G).



Step 3

Grab the top of the middle frame section where marked "CLOSE" (fig. K). Lift slightly and slowly walk towards partner as the frame folds in. Keep walking until the frame is about halfway closed. Take care to avoid pinching your hands or fingers. Hold outside legs and continue closing canopy as you walk towards your partner. Canopy should now look like (fig. L).



Step 4

With the canopy standing, unzip the wheeled bag (loosen cord for WX8) and slide bag down slowly (fig. M) until entire canopy is in. Invert the canopy and zipper shut (fig. N).



If your canopy came with a PE top, please remove this before inserting the frame into the bag.

Wheeled Bag



Bravo Sports, 12801 Carmenita Rd, Santa Fe Springs, CA 90670

Customer Service Dept. Phone (800) 248-5327

E-mail: custserv@variflex.com Check us out at www.variflex.com